

ORDERING INFORMATION

MODEL : R7G4HML-6-YVF4

PLEASE FILL IN THIS SECTION



Model
Company
Name
P/O No.

FACTORY USE ONLY



Job No.	Approved by (Sales office)
Ser No.	Issued by (Sales office)
Sales	Approved by (Factory)
	Set by (Factory)
Ser No.	

Specify the items you want to change. Default setting will be used if not specified.
 DEFAULT shows values in case of nothing specified.

■ OUTPUT RANGE

CHANNEL	SET VALUE	DEFAULT VALUE	Factory Internal check
Output 0	☐ -10 to +10V DC ☐ -5 to +5V DC ☐ -1 to +1V DC ☐ 0 to 10V DC ☐ 0 to 5V DC ☐ 1 to 5V DC ☐ 0 to 1V DC ☐ -0.5 to +0.5V DC ☐ CH Disable	-10 to +10V DC	☐
Output 1	☐ -10 to +10V DC ☐ -5 to +5V DC ☐ -1 to +1V DC ☐ 0 to 10V DC ☐ 0 to 5V DC ☐ 1 to 5V DC ☐ 0 to 1V DC ☐ -0.5 to +0.5V DC ☐ CH Disable	-10 to +10V DC	☐
Output 2	☐ -10 to +10V DC ☐ -5 to +5V DC ☐ -1 to +1V DC ☐ 0 to 10V DC ☐ 0 to 5V DC ☐ 1 to 5V DC ☐ 0 to 1V DC ☐ -0.5 to +0.5V DC ☐ CH Disable	-10 to +10V DC	☐

CHANNEL	SET VALUE	DEFAULT VALUE	Factory Internal check
Output 3	☐ -10 to +10V DC ☐ -5 to +5V DC ☐ -1 to +1V DC ☐ 0 to 10V DC ☐ 0 to 5V DC ☐ 1 to 5V DC ☐ 0 to 1V DC ☐ -0.5 to +0.5V DC ☐ CH Disable	-10 to +10V DC	☐

For CH Disable, default value is used.

■ Scaled range

Scaled range for each channel (scaled range Zero to scaled range Span)

CHANNEL	AVAILABLE RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
Output 0	-32,000 to +32,000	to	0 to 10,000	☐
Output 1	-32,000 to +32,000	to	0 to 10,000	☐
Output 2	-32,000 to +32,000	to	0 to 10,000	☐
Output 3	-32,000 to +32,000	to	0 to 10,000	☐

■ OUTPUT RESET VALUE *1

CHANNEL	AVAILABLE RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
Output 0	-15.00 to +115.00 [%]		-15.00 [%]	☐
Output 1	-15.00 to +115.00 [%]		-15.00 [%]	☐
Output 2	-15.00 to +115.00 [%]		-15.00 [%]	☐
Output 3	-15.00 to +115.00 [%]		-15.00 [%]	☐

*1. When output range is -10 – +10 V DC, approx.-11.5 V DC at approx.-7.5 – -15% and approx.+11.5 V DC at approx.107.5 – 115% are outputted respectively.

■ OUTPUT FUNCTION AT THE LOSS OF COMMUNICATION

ITEM	AVAILABLE RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
Output function at the loss of communication	Choose from right	☐ Hold the output ☐ Output reset value	Hold the output	☐