

ORDERING INFORMATION

Model: R7G4HH-A-YVF4

PLEASE FILL IN THIS SECTION



Model
Company
Name
P/O No.

FACTORY USE ONLY



Job No.	Approved by (Sales office)
Ser No.	Issued by (Sales office)
Sales Rep.	Approved by (Factory)
	Issued by (Factory)
	Ser No.

Specify the items you want to change. Default setting will be used if not specified.
DEFAULT shows values in case of nothing specified.

■ OUTPUT RANGE SETTING

CHANNEL	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT 0	☐ -10 to +10 V DC	-10 to +10 V DC	☐
	☐ -5 to +5 V DC		
	☐ -1 to +1 V DC		
	☐ 0 to 10 V DC		
	☐ 0 to 5 V DC		
	☐ 1 to 5 V DC		
	☐ 0 to 1 V DC		
	☐ -0.5 to +0.5 V DC		
	☐ CH DISABLE		
OUTPUT 1	☐ -10 to +10 V DC	-10 to +10 V DC	☐
	☐ -5 to +5 V DC		
	☐ -1 to +1 V DC		
	☐ 0 to 10 V DC		
	☐ 0 to 5 V DC		
	☐ 1 to 5 V DC		
	☐ 0 to 1 V DC		
	☐ -0.5 to +0.5 V DC		
	☐ CH DISABLE		
OUTPUT 2	☐ -10 to +10 V DC	-10 to +10 V DC	☐
	☐ -5 to +5 V DC		
	☐ -1 to +1 V DC		
	☐ 0 to 10 V DC		
	☐ 0 to 5 V DC		
	☐ 1 to 5 V DC		
	☐ 0 to 1 V DC		
	☐ -0.5 to +0.5 V DC		
	☐ CH DISABLE		
OUTPUT 3	☐ -10 to +10 V DC	-10 to +10 V DC	☐
	☐ -5 to +5 V DC		
	☐ -1 to +1 V DC		
	☐ 0 to 10 V DC		
	☐ 0 to 5 V DC		
	☐ 1 to 5 V DC		
	☐ 0 to 1 V DC		
	☐ -0.5 to +0.5 V DC		
	☐ CH DISABLE		

For CH Disable, default value is used.

■ TRANSFER RATE SETTING

PARAMETER	SET VALUE	DEFAULT VALUE	Factory Internal check
TRANSFER RATE	☐ 12 Mbps	12 Mbps	☐
	☐ 6 Mbps		

■ STATION ADDRESS SETTING

PARAMETER	SETTING RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
STATION ADDRESS	Full-duplex: 01H to 39H Half-duplex: 01H to 3CH		01H	☐

■ SCALING SETTING

Set zero and full scale to each channel (zero scale to full scale)

CHANNEL	SETTING RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT 0	-32,000 to +32,000	to	0 to 10,000	☐
OUTPUT 1	-32,000 to +32,000	to	0 to 10,000	☐
OUTPUT 2	-32,000 to +32,000	to	0 to 10,000	☐
OUTPUT 3	-32,000 to +32,000	to	0 to 10,000	☐

■ OUTPUT CLEAR VALUE SETTING

CHANNEL	SETTING RANGE	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT 0	-15.00 to +115.00 (%)		-15.00 (%)	☐
OUTPUT 1	-15.00 to +115.00 (%)		-15.00 (%)	☐
OUTPUT 2	-15.00 to +115.00 (%)		-15.00 (%)	☐
OUTPUT 3	-15.00 to +115.00 (%)		-15.00 (%)	☐

*1. When output range is -10 to +10V DC, approx. -11.5V DC at approx. -7.5 to -15% and approx. 11.5V DC at approx. 107.5 to 115% are outputted respectively.

■ OUTPUT AT THE LOSS OF COMMUNICATION SETTING

PARAMETER	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT AT THE LOSS OF COMMUNICATION	☐ Hold the output	Hold the output	☐
	☐ Output reset value		