

# ORDERING INFORMATION

# MODEL : R7E-YS2

## PLEASE FILL IN THIS SECTION



Model
Company
Name
P/O No.

## FACTORY USE ONLY



Job No.	Approved by (Sales office)
Ser No.	Issued by (Sales office)
Sales	Approved by (Factory)
	Set by (Factory)
	Ser No.

**Specify the items you want to change. Default setting will be used if not specified.**

DEFAULT shows values in case of nothing specified.

### ■ ETHERNET PARAMETERS

ITEM	AVAILABLE VALUE	SET VALUE	DEFAULT VALUE	Factory Internal check
IP Address	0 to 255 (integer)		192.168.0.1	<input type="checkbox"/>
Subnet Mask			255.255.255.0	<input type="checkbox"/>
Linger	0 to 32767 (integer) TCP Socket closed after no communication (Set 1800 for 180.0 sec.) for the preset time.		1800	<input type="checkbox"/>
			1800	
			1800	
			1800	

### ■ OUTPUT AT THE LOSE OF COMMUNICATION (BASIC MODULE)

ITEM	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT AT THE LOSE OF COMMUNICATION	<input type="checkbox"/> Hold the output (maintains the last data received normally)	Hold the output	<input type="checkbox"/>
	<input type="checkbox"/> Reset the output (to -15%)		

### ■ EXTENSION

ITEM	SET VALUE	DEFAULT VALUE	Factory Internal check
EXTENSION	<input type="checkbox"/> No extension	No extension	<input type="checkbox"/>
	<input type="checkbox"/> Discrete input, 8 points / 16 points		
	<input type="checkbox"/> Discrete output, 8 points / 16 points		

■ OUTPUT AT THE LOSE OF COMMUNICATION (EXTENSION MODULE)

ITEM	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT AT THE LOSE OF COMMUNICATION	<input type="checkbox"/> Hold the output (maintains the last data received normally)	Hold the output	<input type="checkbox"/>
	<input type="checkbox"/> Reset the output (turned off)		

■ SCALING

Set zero and full scale to each channel (zero scale to full scale)

CHANNEL	AVAILABLE VALUE	SET VALUE	DEFAULT VALUE	Factory Internal check
OUTPUT 0	-32000 to +32000	to	0 to 10000	<input type="checkbox"/>
OUTPUT 1	-32000 to +32000	to	0 to 10000	<input type="checkbox"/>