

ORDERING INFORMATION

MODEL : R3-PA8, R3S-PA8

PLEASE FILL IN THIS SECTION



Model
Company
Name
P/O No.

FACTORY USE ONLY



Job No.	Approved by (Sales office)
Ser No.	Issued by (Sales office)
Sales	Approved by (Factory)
	Set by (Factory)

Specify the items you want to change. Default setting will be used if not specified.
 DEFAULT VALUE shows values in case of nothing specified.

■ FUNCTION SETTING

ITEM	AVAILABLE VALUE	SET VALUE	DEFAULT VALUE	Factory Internal check
Manual count reset input	OFF: Invalid ON: Valid	<input type="checkbox"/> OFF <input type="checkbox"/> ON	OFF	<input type="checkbox"/>
Count setting from host PC/PLC *1	OFF: Count reset ON: Count preset	<input type="checkbox"/> OFF <input type="checkbox"/> ON	OFF	<input type="checkbox"/>

*1. It is available only in combination with firmware version V2.00 or later of R3-NE1 or R3-NM1 or, firmware version V1.00 or later of R3-NM3.

With option code 'PRS', above mentioned count preset from host PC/PLC is disregarded.

■ RANGE SETTING

ITEM	AVAILABLE VALUE	SET VALUE	DEFAULT VALUE	Factory Internal check
CH1 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH1 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH2 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH2 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH3 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH3 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH4 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH4 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH5 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH5 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH6 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH6 Min pulse count *2	0 or 1		0	<input type="checkbox"/>
CH7 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH7 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>
CH8 Max. pulse range	10 000 to 2 147 483 647		9 999 999	<input type="checkbox"/>
CH8 Min. pulse count *2	0 or 1		0	<input type="checkbox"/>

*2. Min. pulse count refers to recount start value at counter over flow.

For reset with reset switch, reset with reset signal or count reset from host, it is reset to '0' regardless of min. pulse count setting.