

H: 2-WIRE CURRENT PULSE

ON CURRENT 0 – 25 mA	mA	14.5 mA	Detects as “High” at ≥ 14.5 mA (default if not otherwise specified); Receiving resistor 100 Ω
OFF CURRENT 0 – 25 mA	mA	9.5 mA	Detects as “Low” at ≤ 9.5 mA (default if not otherwise specified); Receiving resistor 100 Ω
FILTER (See next page)	<input type="checkbox"/> With 1 <input type="checkbox"/> With 2 <input type="checkbox"/> W/O	W/O (without)	With 1: chattering protection (10 ms*1) With 2: noise protection (0.1 ms*1)

*1. Time constant

*2. Available range depends on the excitation supply specifications.

PULSE OUTPUT SETTING Specify when one-shot output is required

PULSE WIDTH 0.030 – 300 msec.	One shot period msec.	50 msec.	Specify within 0.030 – 300 ms.
----------------------------------	--------------------------	----------	--------------------------------

PULSE INPUT SETTING Choose required input-output pulse logic relation and mark with .

OUTPUT WAVEFORM		INPUT WAVEFORM	VOLTAGE PULSE (B, C, D) or 2-WIRE CURRENT PULSE (H)		DRY CONTACT (A)	
			<input type="checkbox"/>		<input type="checkbox"/>	
VOLTAGE PULSE (M, N, P)	Non Reversed	No pulse width conversion	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse rise 	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse drop 	<input type="checkbox"/>		<input type="checkbox"/>	
	Reversed	No pulse width conversion	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse rise 	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse drop 	<input type="checkbox"/>		<input type="checkbox"/>	
OPEN COLLECTOR or POWER PHOTO MOSFET RELAY (A, H)	Non Reversed	No pulse width conversion	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse rise 	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse drop 	<input type="checkbox"/>		<input type="checkbox"/>	
	Reversed	No pulse width conversion	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse rise 	<input type="checkbox"/>		<input type="checkbox"/>	
		One-shot, detecting input pulse drop 	<input type="checkbox"/>		<input type="checkbox"/>	

The pulse width in one-shot means the bold lined section of a pulse waveform.

■ INPUT FILTER

Two types of input filters are available. Both can pass low frequency band. The tables below show examples of the maximum frequency which can pass through the filter when the sensitivity level is set to 2V. The frequency may change according to the sensitivity level. If you use a frequency higher than shown below, choose "W/O filter". Otherwise, input signal itself may be rejected.

• Noise Filter Type 1 (chattering protection)

DC Coupling		AC Coupling	
V p-p (V)	MAX. FREQ. (Hz)	V p-p (V)	MAX. FREQ. (Hz)
5	69	5	22
12	35	12	65
24	89	24	112

• Noise Filter Type 2 (noise protection)

DC Coupling		AC Coupling	
V p-p (V)	MAX. FREQ. (Hz)	V p-p (V)	MAX. FREQ. (Hz)
5	1220	5	256
12	329	12	664
24	851	24	1090