
Screw Terminal Ultra-Slim Signal Conditioners M6N Series

2-INPUT MATH FUNCTION MODULE

(PC programmable)

- **Functions & Features**
- 7.5-mm wide ultra-slim design
- Low profile allows the M6N module mounted in a 120-mm deep panel
- 2-input math functions and signal selector functions
- PC programmable
- High-density mounting
- Power indicator LED



MODEL: M6NXF2-[1][2][3]-R[4]

ORDERING INFORMATION

• Code number: M6NXF2-[1][2][3]-R[4] Specify a code from below for each of [1] through [4].

- (e.g. M6NXF2-S2Z1Z1-R/Q)
- Input 1 range (e.g. 1 5 V DC)
- Input 2 range (e.g. 4 20 mA DC)
- Output range (e.g. 4 20 mA DC)
- Specify the specification for option code /Q (e.g. /C01/SET)

[1] INPUT 1

Current

Z1: Range 0 – 50 mA DC (Input resistance 24.9 Ω) Voltage

S1: Range -1000 - +1000 mV DC (Input resistance 1 M Ω min.) S2: Range -10 - +10 V DC (Input resistance 1 M Ω min.) (Configurator software is used to change the input type and precise range.)

[2] INPUT 2

Same range availability as Input 1 (Configurator software is used to change the input type and precise range.)

[3] OUTPUT

Current Z1: Range 0 - 20 mA DC Voltage V2: Range -10 - +10 V DC V3: Range -5 - +5 V DC (Configurator software is used to change the output type and precise range.)

POWER INPUT

DC Power R: 24 V DC (Operational voltage range 24 V ±10 %, ripple 10 %p-p max.)

[4] OPTIONS

blank: none
/Q: With options (specify the specification)

SPECIFICATIONS OF OPTION: Q (multiple selections)

COATING (For the detail, refer to our web site.) /C01: Silicone coating /C02: Polyurethane coating EX-FACTORY SETTING /SET: Preset according to the Ordering Information Sheet (No. ESU-7848)

FUNCTIONS

PC Configurator Software is used to change function type. **Math Functions**: Temperature compensation (w/o square root extraction) Temperature compensation (with square root extraction)

Pressure compensation (with square root extraction) Pressure compensation (w/o square root extraction) Pressure compensation (with square root extraction) Addition / Subtraction Multiplication Division Signal Selector Functions:

High selector Low selector

RELATED PRODUCTS

• PC configurator software (model: M6CFG) Downloadable at our web site.

A dedicated cable is required to connect the module to the PC. Please refer to the internet software download site or the users manual for the PC configurator for applicable cable types.

GENERAL SPECIFICATIONS

Connection

Input and output: M3 screw terminal (torque 0.5 N·m) Power input: Via the Installation Base (model: M6NBS) or M3 screw terminal (torque 0.5 N·m)

Recommended solderless terminal: Max. 5.8 mm (0.23") wide; Ones with insulation sleeve do not fit.

Applicable wire size: 0.2 – 2.5 mm²

Housing material: Flame-resistant resin (black) Isolation: Input 1 or input 2 to output to power (Negative sides of the input 1 and 2 must be of the same potential.)

Overrange output: -2 - +102 %

(Negative current output is not available.)

Zero adjustment: -2 to +2 % (PC programming)

Span adjustment: 98 to 102 % (PC programming)

Power indicator LED: Green LED turns on when the power is supplied.


Status indicator LED: Orange LED; Blinking patterns indicate different operating status of the transmitter.

Programming: Downloaded from PC; input type and range, output type and range, zero and span, function type and parameters, etc.

For detailed information, refer to the users manual for the PC configurator.

Configurator connection: 2.5 dia. miniature jack; RS-232-C level

Recommended solderless terminal (unit: mm [inch])



INPUT SPECIFICATIONS

■ DC Current: Input resistor incoporated (If not specified, the input range is 4 – 20 mA DC.)

Input range: 0 - 50 mA DC

Minimum span: 2 mA

Offset: Lower range can be any specific value within the input range provided that the minimum span is maintained.

DC Voltage

Code S1 (narrow spans)

Input range: -1000 - +1000 mV DC Minimum span: 100 mV

•Code S2 (wide spans) Input range: -10 - +10 V DC Minimum span: 1 V

Offset: Lower range can be any specific value within the input range provided that the minimum span is maintained. If not specified, the input range is shown below.

S1: 0 - 100 mV DC S2: 1 - 5 V DC

OUTPUT SPECIFICATIONS

DC Current Output range: 0 - 20 mA DC Conformance range: 0 - 20.4 mA DC Minimum span: 1 mA Offset: Lower range can be any specific value within the output range provided that the minimum span is maintained. Load resistance: Output drive 11 V max. (e.g. 4 - 20 mA: 550 Ω [11 V ÷ 20 mA]) If not specified, the output range is 4 – 20 mA DC. DC Voltage Code V2 (wide spans) Output range: -10 - +10 V DC Conformance range: -10.4 - +10.4 V DC Minimum span: 1 V Code V3 (narrow spans) Output range: -5 - +5 V DC Conformance range: -5.2 - +5.2 V DC Minimum span: 0.5 V Offset: Lower range can be any specific value within the output range provided that the minimum span is maintained. Load resistance: Output drive 1 mA max. $(e.g. 1 - 5 V: 5000 \Omega [5 V \div 1 mA])$ If not specified, the output range is shown below. V2: 0 - 10 V DC V3: 1 - 5 V DC

INSTALLATION

Power consumption: Approx. 0.5 W Operating temperature: -20 to +55°C (-4 to +131°F) Operating humidity: 30 to 90 %RH (non-condensing) Mounting: Installation Base (model: M6NBS) or DIN rail Weight: 65 g (2.3 oz)

PERFORMANCE in percentage of span

Overall accuracy: Input accuracy + output accuracy See CALCULATION EXAMPLES OF OVERALL ACURACY • Input accuracy*: (% of max. input range) -1000 - +1000 mV : ±0.05 % -10 - +10 V : ±0.05 % 0 - 50 mA : ±0.1 % • Output accuracy**: ±0.04% of max. output range

*Inversely proportional to the span. For math functions, the input accuracy equals that of either input 1 or 2, whichever is greater, with the following parameter setting:

 $K_1 = K_2 = 1, A_2 = 0\%, X_2 = 100\%$ for temp./press. compensation $K_0 = 0.5, K_1 = K_2 = 1, A_0 = A_1 = A_2 = 0\%$ for four arithmetic functions For selector functions, it equals that of the selected signal. **Inversely proportional to the span. **Temp. coefficient**: $\pm 0.01 \%$ /°C ($\pm 0.006 \%$ /°F) of max. span **Response time**: $\leq 0.5 \text{ sec.} (0 - 90 \%)$ **Line voltage effect**: $\pm 0.1 \%$ over voltage range **Insulation resistance**: $\geq 100 \text{ M}\Omega$ with 500 V DC **Dielectric strength**: 2000 V AC @1 minute (input to output to power to ground)

CALCULATION EXAMPLES OF OVERALL ACCURACY

[Example] Function: Temperature compensation w/o square root extraction; $K_1=K_2=1$, $A_2=0\%$, $X_2=100\%$ Input 1: Type -10 - +10 V / range 1 - 5 V Input 2: Type 0 - 50 mA / range 4 - 20 mA Output: Type 0 - 20 mA / range 4 - 20 mA Input 1 = Max. Input Range (20 V) ÷ Span (4 V) × 0.05% = 0.25% Input 2 = Max. Input Range (50 mA) ÷ Span (16 mA) × 0.1% = 0.31% Output = Max. Output Range (20 mA) ÷ Span (16 mA) × 0.04% = 0.05% Accuracy = 0.31% (input 2 > input 1) + 0.05% = 0.36%

STANDARDS & APPROVALS

EU conformity: EMC Directive EMI EN 61000-6-4 EMS EN 61000-6-2 RoHS Directive


EXTERNAL VIEW

FRONT VIEW (with the cover open) SIDE VIEW **Output Range Selectors** Power LED Q ശ 2345 SW1 Status Indicator LED SW1 Configurator Jack 20 EC Z SW2 Input Range Selectors SW2 Ë S

The DIP switch setting is required to select input and output types before setting a precise range using PC Configurator

Software (model: M6CFG). Refer to the instruction manual for detailed procedures.


EXTERNAL DIMENSIONS & TERMINAL ASSIGNMENTS unit: mm [inch]



*Screwdriver stem diameter: 6 mm [.24"] or less

When mounting, no extra space is needed between units.

SCHEMATIC CIRCUITRY & CONNECTION DIAGRAM



FUNCTIONS

■ FUNCTIONS Math Functions Temperature compensation (w/o square root extraction) K_1X_1 $X_0 =$ $\sqrt{K_2X_2 + A_2}$ X₀ : Compensated flow (linear characteristics) where X1: Uncompensated flow X₂ : Temperature Temperature compensation (with square root extraction) $K_1 \sqrt{X_1}$ $X_0 =$ $\sqrt{K_2X_2 + A_2}$ X₀ : Compensated flow (linear characteristics) where X1: Uncompensated flow X₂ : Temperature Pressure compensation (w/o square root extraction) $\mathbf{X}_0 = \mathbf{K}_1 \mathbf{X}_1 \sqrt{\mathbf{K}_2 \mathbf{X}_2 + \mathbf{A}_2}$ X₀ : Compensated flow (linear characteristics) where X_1 : Uncompensated flow X_2 : Pressure Pressure compensation (with square root extraction) $\mathbf{X}_0 = \mathbf{K}_1 \sqrt{\mathbf{X}_1} \sqrt{\mathbf{K}_2 \mathbf{X}_2 + \mathbf{A}_2}$ where Xo: Compensated flow (linear characteristics) X1: Uncompensated flow X_2 : Pressure Addition / Subtraction $X_0 = K_0 \{ K_1 (X_1 + A_1) + K_2 (X_2 + A_2) \} + A_0$ Multiplication $X_0 = K_0(K_1X_1 + A_1) (K_2X_2 + A_2) + A_0$ Division $K_0(K_1X_1 + A_1)$ $X_0 = - + A_0$ $(K_2X_2 + A_2)$ • Signal Selector Functions High selector $X_0 = X_1$ with $X_1 \ge X_2$ $X_0 = X_2$ with $X_1 < X_2$ Low selector $X_0 = X_2$ with $X_1 \ge X_2$ $X_0 = X_1$ with $X_1 < X_2$ Available range X₀ : Output (%) -2 to +102% X1 through X2 : Input (%) -2 to +102% Ko through K2 : Gain (no unit) ±29.999 Ao through A2 : Bias (%) ±299.99%

Factory default setting: Addition / Subtraction $K_0 = 1, K_1 = 1, K_2 = 1, A_0 = 0\%, A_1 = 0\%, A_2 = 0\%$

