MODEL: M6NXV


Screw Terminal Ultra-Slim Signal Conditioners M6N Series

SIGNAL TRANSMITTER

(PC programmable)

Functions & Features

- 7.5-mm wide ultra-slim design
- Low profile allows the M6N module mounted in a 120-mm deep panel
- Converts a DC input into a standard process signal
- PC programmable
- · High-density mounting
- Power indicator LED



MODEL: M6NXV-[1][2]-R[3]

ORDERING INFORMATION

• Code number: M6NXV-[1][2]-R[3]
Specify a code from below for each of [1] through [3].
(e.g. M6NXV-Z1Z1-R/Q)

- Input range (e.g. 4 20 mA DC)
- Output range (e.g. 4 20 mA DC)
 Specify the specification for option code /Q (e.g. /C01/SET)

[1] INPUT

Current

 $extbf{Z1}$: Range 0 – 50 mA DC (Input resistance 24.9 Ω) Voltage

S1: Range -1000 - +1000 mV DC (Input resistance 1 M Ω min.) **S2**: Range -10 - +10 V DC (Input resistance 1 M Ω min.)

(Configurator software is used to change the input type and precise range.)

[2] **OUTPUT**

Current

Z1: Range 0 - 20 mA DC

Voltage

V2: Range -10 - +10 V DC **V3**: Range -5 - +5 V DC

(Configurator software is used to change output over the described range of the selected suffix code.

For changing between suffix codes, set the Output Range Selector on the side of unit before software adjustment.)

POWER INPUT

DC Power

R: 24 V DC

(Operational voltage range 24 V ±10 %, ripple 10 %p-p max.)

[3] OPTIONS

Other Options **blank**: none

/Q: Option other than the above (specify the specification)

SPECIFICATIONS OF OPTION: Q (multiple selections)

COATING (For the detail, refer to our web site.)

/C01: Silicone coating /C02: Polyurethane coating EX-FACTORY SETTING

/SET: Preset according to the Ordering Information Sheet

(No. ESU-7832)

RELATED PRODUCTS

• PC configurator software (model: M6CFG)

Downloadable at our web site.

A dedicated cable is required to connect the module to the PC. Please refer to the internet software download site or the users manual for the PC configurator for applicable cable types.

GENERAL SPECIFICATIONS

Connection

Input and output: M3 screw terminal (torque 0.5 N·m) **Power input**: Via the Installation Base (model: M6NBS)

or M3 screw terminal (torque 0.5 N·m)

Recommended solderless terminal: Max. 5.8 mm (0.23")

wide; Ones with insulation sleeve do not fit.

Applicable wire size: 0.2 - 2.5 mm² **Screw terminal**: Nickel-plated steel

Housing material: Flame-resistant resin (black)

Isolation: Input to output to power **Overrange output**: -2 - +102 %

(Negative current output is not available.) **Zero adjustment**: -2 to +2 % (PC programming) **Span adjustment**: 98 to 102 % (PC programming)

Power indicator LED: Green LED turns on when the power is

supplied.

Status indicator LED: Orange LED; Blinking patterns indicate

different operating status of the transmitter.

MODEL: M6NXV


Programming: Downloaded from PC; input type and range, output type and range, zero and span, user's linearization table (max. 101 points, specified within -2 to +102% for both input and output), etc.

For detailed information, refer to the users manual for the PC configurator.

Configurator connection: 2.5 dia. miniature jack;

RS-232-C level

■Recommended solderless terminal (unit: mm [inch])



INPUT SPECIFICATIONS

■ DC Current: Input resistor incoporated

(If not specified, the input range is 4 – 20 mA DC.)

Input range: 0 – 50 mA DC Minimum span: 2 mA

Offset: Lower range can be any specific value within the input range provided that the minimum span is maintained.

■ DC Voltage

Code S1 (narrow spans)

Input range: -1000 - +1000 mV DC

Minimum span: 100 mV •Code S2 (wide spans) Input range: -10 - +10 V DC

Minimum span: 1 V

Offset: Lower range can be any specific value within the input range provided that the minimum span is maintained.

If not specified, the input range is shown below.

S1: 0 - 100 mV DC S2: 1 - 5 V DC

OUTPUT SPECIFICATIONS

■ DC Current

Output range: 0 - 20 mA DC

Conformance range: 0 - 20.4 mA DC

Minimum span: 1 mA

Offset: Lower range can be any specific value within the output range provided that the minimum span is

maintained.

Load resistance: Output drive 11 V max. (e.g. 4 - 20 mA: $550 \Omega [11 V \div 20 mA]$)

If not specified, the output range is 4 - 20 mA DC.

DC Voltage

Code V2 (wide spans)

Output range: -10 - +10 V DC

Conformance range: -10.4 - +10.4 V DC

Minimum span: 1 V Code V3 (narrow spans) Output range: -5 - +5 V DC

Conformance range: -5.2 - +5.2 V DC

Minimum span: 0.5 V

Offset: Lower range can be any specific value within the output range provided that the minimum span is

maintained.

Load resistance: Output drive 1 mA max. (e.g. 1 – 5 V: 5000 Ω [5 V ÷ 1 mA])

If not specified, the output range is shown below.

V2: 0 - 10 V DC V3: 1 - 5 V DC

INSTALLATION

Power consumption: Approx. 0.5 W

Operating temperature: -20 to +55°C (-4 to +131°F)
Operating humidity: 30 to 90 %RH (non-condensing)
Mounting: Installation Base (model: M6NBS) or DIN rail

Weight: 65 g (2.3 oz)

PERFORMANCE in percentage of span

Overall accuracy: Input accuracy + output accuracy

Inversely proportional to the span.

See CALCULATION EXAMPLES OF OVERALL ACURACY.

• Input accuracy: (% of max. input range)

-1000 - +1000 mV : ±0.01 % -10 - +10 V : ±0.01 % 0 - 50 mA : ±0.02 %

• Output accuracy: ±0.04 % of max. output range

Temp. coefficient: ±0.01 %/°C (±0.006 %/°F) of max. span

Response time: ≤ 0.5 sec. (0 - 90 %)

Line voltage effect: ± 0.1 % over voltage range Insulation resistance: ≥ 100 M Ω with 500 V DC

Dielectric strength: 2000 V AC @1 minute (input to output

to power to ground)

CALCULATION EXAMPLES OF OVERALL ACCURACY

[Example] Input Type -10 - +10 V, Input Range 1 - 5 V,

Output Type -5 - +5 V, Output Range 1 - 5 V

• Input accuracy = Max. Input Range (20 V) \div Span (4 V) \times

0.01 % = 0.05 %

• Output accuracy = Max. Output Range (10 V) \div Span (4 V) \times 0.04 % = 0.1 %

Accuracy= ±0.15 %

STANDARDS & APPROVALS

EMC Directive EMI EN 61000-6-4 EMS EN 61000-6-2 RoHS Directive

EXTERNAL VIEW

Power LED
Status Indicator LED
Configurator Jack


Configurator Jack

Status Indicator LED
St

The DIP switch setting is required to select output types before setting a precise output range using PC Configurator Software (model: M6CFG).

Refer to the instruction manual for detailed procedures.

EXTERNAL DIMENSIONS & TERMINAL ASSIGNMENTS unit: mm [inch]




^{*}Screwdriver stem diameter: 6 mm [.24"] or less

When mounting, no extra space is needed between units.

MODEL: M6NXV

SCHEMATIC CIRCUITRY & CONNECTION DIAGRAM



 Λ

Specifications are subject to change without notice.